





3 types of stacking kits:

SK-DH	
8806071037578	
	
DRY	SDC14719/XEN SDC3D819/XEN SDC3C811/XEN SDC35711/XEN DV91F5E6HGW/EN DV81K6010CW/EN DV81F5E5HGW/EN DV71F5E0HGW/EN DV91H8000HW/EN DV81H8100HW/EN DV81H4100CW/EN

SK-DA	
8806071054285	
	
	SDC14719/XEN SDC3D819/XEN SDC3C811/XEN SDC35711/XEN DV91F5E6HGW/EN DV81K6010CW/EN DV81F5E5HGW/EN DV71F5E0HGW/EN DV91H8000HW/EN DV81H8100HW/EN DV81H4100CW/EN

SKK-DF	
8806085613690	
	
	SDC14719/XEN SDC3D819/XEN SDC3C811/XEN SDC35711/XEN DV91F5E6HGW/EN DV81K6010CW/EN DV81F5E5HGW/EN DV71F5E0HGW/EN DV91H8000HW/EN DV81H8100HW/EN DV81H4100CW/EN


SKK-DD	
8806088662923	
	
	All 600*600/550 models

WM	WF916P4SAWQ/EN WF816P4SAWQ/EN WF716P4SAWQ/EN WW91H7400EW/EN WW81H7400EW/EN WF0714F7W WW91J6600CW/EN WW81J6600CW/EN WW91K7605OW/EN WW81K7605OW/EN WW91K6604QW/EN WW81K6604QW/EN
-----------	---


	WF712Y4BKWQ/EN WF710Y4BKWQ/EN WF8602 WF8604 WF8614 WW71J3473KW/EN
--	--

	WF1124ZAC/XEN WF91F5EBP4W/EN WF81F5E5P4W/EN WF81F5E3P4W/EN WF81F5E5Q4W/EN WF81F5ECW4W/EN WF81F5E0Q4W/EN WF71F5E5P4W/EN WF71F5E3P4W/EN WF71F5E5Q4W/EN WF71F5E2Q4X/EN WF71F5E2Q4W/EN WF71F5E0Q4W/EN WF71F5ECW4W/EN WF71F5E0Z4W/EN WW10H9600EW/EG WW12H8400EW/EN WW81J3473KW/EN WW91J6400CW/EN WW81J6400CW/EN WW12K8402OW/EN WW91K6404QW/EN WW81K6404QW/EN WW81K5400WW/EN WW71K5400UW/EN WW71K5400WW/EN
--	---


	All 600*600/550 models
--	------------------------




1. Carefully lay the dryer on its side.




2. Install rubber pads to dryer base.
• Locate the 4 rubber pads in the parts package. Insert the rubber pads into the holes at the bottom of the levelling legs.
• Purchase the stacking-kit package additionally.



3. Set the dryer upright.



4. Install bracket to dryer.
• Remove washer top cap screw from the rear left. Align left bracket holes with top cap screw hole on rear left of the unit and replace screw.
Leave screw loose so dryer hole alignment will be easier.
• Repeat the above step with the right side.



5. Install dryer and bracket on washer

